

PEPCARE

Nose/ear hair trimmer (Battery operation) Art. 15154012

GB Operating Manual

1. About these Instructions

- Before using the shaver for the first time, read the Instructions for Use carefully and ensure you comply with the safety instructions!
- The shaver should only be used as described in these instructions.
- Keep these instructions for reference.
- If you pass the shaver on to someone else, please include these instructions.



Warnings in these instructions

If necessary, the following warnings will be used in these operating instructions:



DANGER! High risk: Failure to observe this warning may result in injury to life and limb.

WARNING! Moderate risk: Failure to observe this warning may result in injury or serious material damage.

CAUTION: Low risk: Failure to observe this warning may result in minor injury or material damage.

NOTE: Circumstances and specifics that must be observed when handling the device.

2. Safety Instructions

Intended use

The men's shaver is intended exclusively for trimming human nose and ear hair. The shaver is designed for private home use and must not be used for commercial purposes. The shaver must only be used indoors.

Possible misuse

Do not use the device to cut artificial hair or animal hair.

Instructions for a safe operation

- This device may be used by children older than 8 years, people with reduced physical, sensory or mental faculties, as well as people without experience or who do not know the device. This applies as long as they are supervised or have been instructed on the safe use of the device and have understood the related dangers.
- Children must be supervised to ensure that they do not play with the device.
- Cleaning and user maintenance shall not be carried out by children without supervision.
- Keep the device and accessories out of children's reach.



DANGER for children

- Children must not play with packaging material. Do not allow children to play with plastic bags. Danger of suffocation.

Batteries

- Batteries are dangerous and can cause death if swallowed. For this reason, store batteries out of the reach of small children. If a battery has been swallowed, a doctor must be consulted immediately.
- When inserting the battery, observe the correct polarity.
- If the device will not be used for an extended period of time, remove the battery. The battery could leak and damage the device.
- Do not expose the batteries to extreme conditions, do not place them on heaters and do not expose them to direct sunlight. Otherwise there is an increased danger of the batteries leaking.
- Batteries must not be charged or reactivated in any other way, must not be disassembled, disposed of in a fire, or short-circuited.
- When battery acid has leaked, avoid contact with skin, eyes and mucous membranes. In the event of contact with the acid, rinse the affected areas liberally with clear water and consult a doctor immediately.

WARNING! Risk of injury

- Do not insert the nose/ear hair trimmer attachment too far into your nostril or ear.
- Do not use the device on injured skin (e.g. open wounds or swellings, rash, sunburn).
- Before using the device, ensure the attachments are in a proper condition. Do not use defective attachments.
- Do not operate the device if the device shows visible signs of damage or if the device has been dropped.
- Switch off the device before pinning up or changing the attachments and each time before cleaning.
- Keep the device away from your eyes.
- To avoid any risk, do not make any changes to the device or accessories. Repairs must only be carried out by a specialised company.

WARNING! Risk of material damage

- Protect the device from moisture, dripping water or splash water.
- Do not use any harsh or abrasive cleaning agents.

3. Operation

WARNING!

- Do not insert the nose/ear hair trimmer attachment too far into your nostril or ear.
- Do not use the device on injured skin (e.g. open wounds or swellings, rash, sunburn).

Inserting the battery

Use a 1.5 V LR6 (AA) battery as power supply.

1. Move the on/off switch downwards, to switch off the device.
2. Turn the device so that the battery compartment cover is at the top.
3. Slightly turn the battery compartment cover anti-clockwise and pull it off.
4. If necessary, remove the old battery. Insert a new battery. The negative terminal (-) must be directed towards the battery compartment cover.
5. Place the battery compartment cover upon the device again and move it slowly in clockwise direction until it engages with a "click" sound.

Nose/ear hair trimmer attachment

The nose/ear hair trimmer attachment is destined for cutting nose and ear hair.

1. Take off the protective cap.
2. Check that the attachment is in place.
3. Move the on/off switch upwards to switch on the device.
4. Slowly insert the metal tip into one of your nostrils or ears.
5. Move the device in circles to cut the hair.
6. Move the on/off switch downwards to switch off the device, and clean it.

4. Technical Data

Article no.	15154012
Battery	1.5 V LR6 (AA)

In the interest of product improvements, we reserve the right to make technical and optical changes to the device and accessories.

5. Scope of Delivery

Nose/ear hair trimmer, protective cap, 1x 1.5 V LR06 (AA) alkaline battery, cleaning brush, operating instructions

6. Disposal



This symbol indicates that the product must be disposed of in a separate waste collection within the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices.



Batteries must not be disposed of in domestic waste. Used batteries must be disposed of properly. For this purpose, retailers selling batteries and the municipal waste collection points provide containers for disposing of batteries.



Packaging

If you want to dispose of the packaging, make sure you comply with the environmental regulations applicable in your country.

7. Warranty – Service

Dear customer:

As a matter of course, this article is provided with the statutory warranty period of two years.

In terms of the warranty handling, please consult the seller of the goods.

Within the framework of the statutory provisions, a defect exists if it can be attributed to material, processing or construction defects. Excluded are damages resulting from natural wear and tear, wrong care or improper use.

If you need help in using the article or would like to receive further product information, you may visit our service platform www.aquarius-service.com or contact support@aquarius-service.com.

NOTE:

The operating instructions for this product are available as PDF on www.aquarius-serice.com.

Produced for: Aquarius Deutschland GmbH,
Adalperostrasse 29, 85737 Ismaning bei München.